



- typical office layout in new construction
- 1 main entrance (aorta) with transparent facades at the points of ascension
 - 2 offices
 - 3 consultation room
 - 4 decentral repro unit
 - 5 lockers and pigeon holes
 - 6 office buffer
 - 7 void (if the floor bay is closed; with department table and consultation niches)

